



X2 RACELINK

LUMIRANK
DRIVER INFO DISPLAY

Installation Guide

SYSTEM SET UP

- > 1x **A)** SAS - M8 12V Power Cable
- > 1x **B)** MyLaps X2 Racelink with RF Antenna & GPS Antenna
- > 1x **D)** STS / LUMIRANK Driver Info Display
- > 1x **E)** ML M8 Y Cable (Female / Male / Female)
- > 1x **F)** SAS M8/DTM/ DEUTSCH / Log. Connection Cable (for X2 Racelink **PRO only**)



Connection INFO

SYSTEM Connection

- A)** SAS- M8 12V Power Cable > connect to MAIN VDD (on during PitStop)
- B)** MyLaps X2 RaceLink > Antenna needs to be mounted on the roof
- D)** STS / LUMIRANK Driver Info Display > Must be visible to the driver - connect to M8 Y
- E)** ML M8 Y Cable (Female / Male / Female) > connect LR & DID & X2 RacLink
- F)** SAS M8/DTM/ DEUTSCH / Logger > use only on X2Pro and for Logger connection.

